




Assembly and Operating Instructions

SECURY Automatic, A-opener, Cable Duct, 24V DC



Potential-free contact for external:
 - Intercom
 - Switch
 - Home automation system



110V AC, 60Hz

- Potential-free contact = by other
- Intercom = by other
- Switch = by other
- Power supply (not supplied) = 110V AC, 60Hz to 24V DC, 1.3A
- Cable duct = 6-29854-00-0-0
- SECURY Automatic = 6-28485-XX-0-8
- A-opener = K-18153-01-0-1

Ferco Architectural Hardware Inc.
 2000, Rue Berlier
 Laval QC H7L 4S4
 T 450.973.1437
 F 450.973.7661
 1.800.355.8810
 www.ferco.ca

Securing technology for you

