

# SFW05-AT

REPLACEMENT PARTS LIST • LISTA DE PARTES DE REPUESTA • LISTE DE PIÈCES DE RECHANGE

SFW05-AT

PART NO.	DESCRIPTION	DESCRIPCIÓN	BESCHREIBUNG	DÉSIGNATION
SFW05AT01-1	SCREW	TORNILLO	SCHRAUBE	VIS
SFW05AT02-1	EXHAUST COVER	CUBIERTA	ABDECKUNG	COUVERCLE
SFW05AT03-1	CYLINDER CAP	CILINDRO TAPA	ZYLINDER KAPPE	CYLINDRE BOUCHON
SFW05AT04-1	GASKET	SELLO	DICHTUNG	JOINT
SFW05AT05-1	SEAL	SELLO	DICHTUNG	JOINT
SFW05AT06-1	O-RING	SELLO	DICHTUNG	JOINT
SFW05AT07-1	SPRING	RESORTE	FEDER	RESSORT
SFW05AT08-1	O-RING	SELLO	DICHTUNG	JOINT
SFW05AT09-1	VALVE	VÁLVULA	VENTIL	VALVE
SFW05AT10-1	O-RING	SELLO	DICHTUNG	JOINT
SFW05AT11-1	COLLAR	COLLAÍN	KRAGEN	COLLET
SFW05AT12-1	O-RING	SELLO	DICHTUNG	JOINT
SFW05AT13-1	O-RING	SELLO	DICHTUNG	JOINT
SFW05AT14-1	PISTON ASSEMBLY	ASAMBLE DE PISTON	KOLBEN-ZUSAMMENBAU	ENSEMBLE PISTON-COUTEAU
SFW05AT15-1	O-RING	SELLO	DICHTUNG	JOINT
SFW05AT16-1	CYLINDER	CILINDRO	ZYLINDER	CYLINDRE
SFW05AT17-1	BUMPER	AMORTIGUADOR	PUFFER	AMORTISSEUR
SFW05AT18-1	JOINT GUIDE	CONJUNTO	GELENK	JOINT
SFW05AT19-1	BODY	CARCASA	GEHÄUSE	CORPS
SFW05AT20-1	SEAL	SELLO	DICHTUNG	JOINT
SFW05AT21-1	TRIGGER VALVE HEAD	ASAMBLE DE VÁLVULA	VENTIL-ZUSAMMENBAU	VALVE D'ASSEMBLÉE
SFW05AT22-1	O-RING	SELLO	DICHTUNG	JOINT
SFW05AT23-1	TRIGGER VALVE GUIDE	ASAMBLE DE VÁLVULA	VENTIL-ZUSAMMENBAU	VALVE D'ASSEMBLÉE
SFW05AT24-1	O-RING	SELLO	DICHTUNG	JOINT
SFW05AT25-1	TRIGGER VALVE STEM	ASAMBLE DE VÁLVULA	VENTIL-ZUSAMMENBAU	VALVE D'ASSEMBLÉE
SFW05AT26-1	BRACKET	SOPORTE	HALTERUNG	SUPPORT DE FIXATION
SFW05AT27-1	SPRING	RESORTE	FEDER	RESSORT
SFW05AT28-1	LOCKING WASHER	ARANDELA DE CIERRE	SICHERUNGSSCHEIBE	RONDELLE VERROUILLAGE
SFW05AT29-1	TRIGGER	GATILLO	AUSLÖSER	GÂCHETTE
SFW05AT30-1	PIN	PASADOR	STIFT	GOUPILLE
SFW05AT31-1	SCREW	TORNILLO	SCHRAUBE	VIS
SFW05AT32-1	DRIVER GUIDE	GUÍA	FÜHRUNG	GUIDE
SFW05AT33-1	SPRING PIN	RESORTE PASADOR	FEDER STIFT	RESSORT GOUPILLE
SFW05AT34-1	FRONT PLATE	PLACA	PLATTE	PLAQUE
SFW05AT35-1	FIXED MAGAZINE UNIT	ASAMBLE DE CARRIL	SCHIENE-ZUSAMMENBAU	RAIL D'ASSEMBLÉE
SFW05AT36-1	SCREW	TORNILLO	SCHRAUBE	VIS
SFW05AT37-1	STOP	TOPPE	PUFFER	ARRÊT
SFW05AT38-1	SCREW	TORNILLO	SCHRAUBE	VIS
SFW05AT39-1	MOVABLE MAGAZINE UNIT	ASAMBLE DE CARRIL	SCHIENE-ZUSAMMENBAU	RAIL D'ASSEMBLÉE
SFW05AT40-1	PIN	PASADOR	STIFT	GOUPILLE
SFW05AT41-1	WHEEL	RUEDA	RAD	ROUE
SFW05AT42-1	TENSION SPRING	MUELLE DE TENSIÓN	TENSIONSFEDER	RESSORT DE TENSION
SFW05AT43-1	FEEDER SHOE	ALIMENTADOR	NAGELSCHIEBER	POUSSOIR
SFW05AT44-1	SPRING WASHER	RESORTE ARANDELA	DICHTUNG SCHEIBE	JOINT RONDELLE
SFW05AT45-1	NUT	TUERCA	MUTTER	ÉCROU
SFW05AT46-1	SUPPORT	SOPORTE	HALTERUNG	SUPPORT DE FIXATION
SFW05AT47-1	SCREW	TORNILLO	SCHRAUBE	VIS
SFW05AT48-1	PIN	PASADOR	STIFT	GOUPILLE
SFW05AT49-1	TORSION SPRING	MUELLE DE TORSIÓN	TORSIONSFEDER	RESSORT DE TORSION
SFW05AT50-1	LOCK	TRABAR	VERRIEGELN	VERROUILLER
SFW05AT51-1	NUT	TUERCA	MUTTER	ÉCROU
SFW05AT52-1	SOFT GRIP SLEEVE	AGARRADERO	GRIFF	GAINÉ DE CUIR
SFW05AT53-1	O-RING	SELLO	DICHTUNG	JOINT
SFW05AT54-1	END CAP	TAPA	KAPPE	BOUCHON
SFW05AT55-1	AIR PLUG	AIRE ENCHUFE	LUFTSTECKER	L'AIR BOUCHON



## AT LIGHT WIRE STAPLER

Parts Reference Guide

Guía de referencia de piezas

Pièces Guide de référence

Schematic Drawings Inside  
Plano esquemático en el interior  
Schéma intérieur

# SENCO®

Verpa Senco BV  
Pascallaan 88  
8218 NJ LELYSTAD  
The Netherlands

[www.senco-emea.com](http://www.senco-emea.com)

© 2014 by Senco Brands, Inc.

Rev. VS14SFWAT04\_25-06-2014

EU DESIGNED PARTS CAN BE DIFFERENT

